

Specification and Manual

Customer :				
Description :	: Air Conditioner for Equipment (Through Wall Mounting)			
Customer Part No.: Rev.:				
Delta Model N	lo. :	HEC0800PB	Rev :	03
Sample Date Code:				
Sample Issue	Date :	SEP.15 2020		

Please send one copy of this specification back after you signed approval for production pre-arrangement

Approved by :

Date :

DELTA ELECTRONICS, INC. 252, SHANG YING ROAD, KUEI SAN TAOYUAN CITY 333, TAIWAN

TEL : 886-(0)3-3591968 FAX : 886-(0)3-3591991

Part no. :		
Delta model no. : HEC0800PB		

Table of content

Des	cription4
Pac	king & Shipping4
Saf	ety Notes4
1.	Product Instruction
2	Electrical Specification142-1. Indicator & Connector142-1-1 Power Supply & Alarm Connector142-1-2 Protection15
3.	Environmental Condition173-1. Operating Temperature173-2. Storage Temperature173-3. Operation Humidity173-4. Ingress Protection Rating17
4.	Reliability Table
5.	Safety Certification
6.	Accessory
7.	Parameters Table187-1. System Setup187-2. Alarm Logs & Fault Processing19
8.	Installation Notice

Part	no. :	
Delt	a model no. : HEC0800PB	
9.	Reclaim	1

Page 3

Description

This document is an installation and the characteristics of Delta HECX1P series. Before installing the unit, please read this manual thoroughly, and following the instructions contained in it. The document is the exclusive property of Delta Electronics, Inc. it should not be distributed, reproduced, or any other format without prior permission of Delta. Specifications are subject to change without notice.

Packing & Shipping

During handling or transport, air conditioner must be upward placed, "**NO**" inverted, flat, excessive tilt and collision. Air conditioner is a precision instrument, it should be handled or transported with care, do not stand on the box, or place heavy objects on it. Please pay attention to the following icons on the package. If air conditioner is toppled, over slanted or dropped unfortunately, please follow below steps: a. stand for 12 hours to ensure refrigerant pressure stability, b. power on and execute self-test to make sure no alarm happened, c. air conditioner keeps 1 hour operating and make sure there is no abnormal acoustic noise.



Safety Notes

Please read the safety notes carefully before installing air conditioning unit and be sure to install it correctly. After completing the installation, make sure that the unit operates properly during the start-up operation.

Meaning of WARNING and CAUTION notices:

▲ Warning:

Failure to follow these instructions properly may result in personal injure or loss life.

▲ Caution:

Failure to observe these instructions properly may result in property damage or personal injury, which may be serious depending on the circumstance.

🖄 Warning:

1. Installation work and electrical wiring must be done by qualified person(s) in accordance with all applicable

codes, standards and national wiring regulations.

- 2. Use this unit only in the manner intended by the manufacturer. If you have questions, please contact the manufacturer.
- 3. Install the air conditioner in accordance with the instructions in this installation manual. Improper installation may result in water leakage, electric shocks or fire.
- 4. Make sure that all wiring is secured, the specified wires are used, and there is no strain on the terminal connections or wires.
- 5. If refrigerant gas leaks during installation, ventilate the area immediately. Do not directly touch refrigerant that has leaked from refrigerant pipes or other areas, as there is a danger of frostbite.
- 6. Before serving or cleaning unit, switch power off and disconnect power supply.
- 7. When cutting or drilling into wall or ceiling, do not damage electrical wiring or hidden utilities.
- 8. Be sure to use only the specified accessories and parts for installation work.
- Protective earth connection: The enclosure must be earthed at the protective earth terminal. Use 2.5 mm² (14 AWG) wire and use spring washer to avoid loosening.
- 10. The air conditioner shall be not accessible to the general public.
- 11. The installation must contain a device to disconnect all poles of the air conditioner from the power supply. The contact distance in all poles must be 3 mm minimum.
- 12. To reduce the risk of electrical shock. Means for disconnection must be incorporated in the fixed wiring in accordance with the wiring rules.
- 13. This appliance is intended to be used by expert or trained users in shops, in light industry and on farms, or for commercial use by lay persons".

\land Caution

- 1. Install the air conditioner on a wall/ door strong enough to withstand the weight of the unit.
- 2. Do not block air inlets or exits.
- 3. Do not install the air conditioner at any place where there is a danger or flammable gas leakage.
- 4. Arrange the drain to ensure complete drainage.
- 5. To avoid injury, do not touch the air inlet or aluminum fins of unit.


Page 5


- 6. Watch your steps at the time of fin cleaning or air conditioner inspection.
- 7. Do not topple the air conditioner while moving or storage.
- 8. The hole in the bottom of the air conditioner should be connected to a sealed container through a drainpipe.
- 9. The appliance is not to be used by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction.
- 10. Children being supervised not to play with the appliance.

Part no. :	
Delta model no. : HEC0800PB	

Specification for Approval

Customer :			
Description : Air conditioner for Equipment with 0800 W Rated Cooling Capacity (Through			
Wall Mounting)			
Customer P/N :	Rev. :		
Delta model no. : HEC0800PB	Rev. : 02		
Sample revision. :	Date Code :		
Sample issue date :	Quantity : one sets		





INTERNAL



1. Product Instruction

1-1. General Description

HEC0800PB is a DC air conditioner with 48 VDC power input, it is designed for IP55 sealed outdoor telecom cabinet to provide stable and optimum internal conditions for equipment and avoid hotspot inside the cabinet.

HEC X1 P B - XXX

(1) (2) (3) (4) (5)


No	Item	Digit	Specification
(1)	Product Message	HEC	Compressor Air Conditioner
(2)	Cooling Capacity	X1	X1=0800
(3)	Operation Voltage	Р	DC 48V for door
(4)	Product Version	В	N/A
(5)	Customer ID	XXX	N/A

1-2. Main Feature & Model Number

Dimensions, Weight & Mounting method				
Dimension (H x W x D) (without flange)	mm (inch)	700 x 500 x 200 (27.7 x 19.8 x 7.9)		
Application		Outdoor		
Weight	Kg (lbs)	28.0 (61.7)		
Mounting Method		Door/Side		
Color (optional)		RAL7035		
Environment	al Protection & Perform	nance		
Operating Temperature Range	°C (°F)	-10 to +55 (+14 to +131)		
Operating Humidity		External : 0~100% RH Internal: 0~80% RH		
Storage Temperature	°C (°F)	-40 to +70 (-40 to +158)		
Storage Relative Humidity	RH	5~95%		
Refrigerant		R134a, 285 g±10 g		
Protection for Dust ,Wind and Water (External)	IEC 60529 /GR487	IP55 / GR487		
Noise (1m)	dB-A	65		
Operating Status	N/A	LED Indicator / Display Board		
Cooling Capacity & Operational Data				
Rated Cooling Capacity at L35/L35	W (Btu/hr)	800 (2720)		
Rated Cooling Current	A	3.9		
Rated Internal Airflow (L35/L35)	m ³ /h (CFM)	350 (205)		
Rated External Airflow (L35/L35)	m³/h (CFM)	390 (230)		


Part no. : Delta model no. : HEC0800PB


Power & Range				
Input Voltage	VDC	48		
Max. Operating DC Current	A	14.3		
Alarm	N/A	Dry Contact Output		
Key Components				
Controller		Built-in Smart Controller		
Fans		Delta High Efficiency Blowers		
Compressor		Rotary, DC		




Delt	a model no. : HEC0800PE	3		

1-3. Dimension











- (1) Material: Case SGCC Sheet.
- (2) Finish: Powder coating 75~120 uM, Color RAL 7035.
- (3) Dimensional Tolerance: ± 1 mm.

Part no. : Delta model no. : HEC0800PB

1-4. Mounting Panel Cutout






Part no. :	
Delta model no. : HEC0800PB	

1-5. Configuration & Maintenance

Make sure the air conditioner surface sealed with mounting flange to avoid water penetrates into shelter through mounting interface. It is suggested to use gaskets sticking on the mounting flange and seal the gap between flange and cabinet with silicone gel during installation. There should be **NO** any gap surround gaskets to avoid water penetrates into enclosure.

The air conditioner is composed as the following key components: they are chassis, cover, controller, heat exchanger, blowers and compressor etc. It is "**not**" recommended that the user replace the compressor, evaporator, and the condenser by themselves; it may damage the system and getting injured.



NO.	Q'TY	DESCRIPTION
1	1	Case Chassis
2	1	Case Cover
3	1	Control Board
4	1	DC Power Board
5	1	Evaporator
6	1	Internal Fan
7	1	Condenser
8	1	External Fan
9	1	Compressor

In order to assure the air conditioner running at optimal condition, the condenser should be cleaned once annually at least; user can clean the condenser with water directly. The external side fan blade can also be cleaned with normal pressure water if there is dust accumulation. Please do not use strong water jet to impact the center of fan and the surface of condenser.

The bottom hole of the air conditioner should be connected to a sealed container through a drainpipe, please clear drain holes when the maintenance. Please also notice that:


- 1. Check wires are connected correctly, and the insulation is not cracking or broken.
- 2. Use Self-test to check the unit running correctly or not. And the supplied air of internal side should be as cooled air.
- 3. Do not wipe the product with organic solvent, volatile substances like toluene or gasoline, it will destroy the powder-coated surface.
- 4. Turn off the power before maintaining.
- 5. Please turn off power and remove dry contact connector while non-operating for a long time.


- 6. If any abnormal acoustic noise from air conditioner happened, please turn off the product and contact with customer services.
- 7. The refrigerant is environmental friendly product of R134a. Little refrigerant leakage (< 5 g/ year) is allowed for application. If refrigerant leakage seriously, please turn off the power and wait for at least 2 hours to make sure the refrigerant fully exhaust. Please also contact the services to replace spare parts.</p>
- 8. The compressor electrical protecting cover is sealed with silicon for IP55 requirement. Please do not dismantle the sealed cover or will lose the quality assurance of the compressor.

1-6. Thermal and Airflow


The internal and external air flow circulation is shown as the figure. Through separated mechanism design, internal and external air flow won't be mixed since the waste heat can be dissipated from the cabinet to the ambience. Internal temperature sensor is placed at return air stream to provide reliable temperature measurement and safety of operation.

The waste heat generated from the internal equipment will be absorbed by the refrigerant through the evaporator and dissipate to the ambience by the condenser of external side.









Delta model no. : HEC0800PB


2 Electrical Specification

2-1. Indicator & Connector

2-1-1 Power Supply & Alarm Connector

Pin	Description	Cable wire size	
1	DC	14 AWG	
2	-48 V	14 AWG	
3	N/A	N/A	
4	N/A	N/A	
5	N/A	N/A	

Pin Description	
3	Alarm+
4	Alarm-



.....

	PIN5	PIN1	
0			0

System alarm default setup

Note: Customers can setup the N.O or N.C by themselves when any alarm happen through display

	Dry-contact output		
display setup	normal	any alarm happen	
1 (System default setup)	Common (C) Normally Closed (NC)	Common (C) Normally Open (NO)	
0	Common (C) Normally Open (NO)	Common (C) Normally Closed (NC)	

board (d1.6 Dry-contact Setup).


• Specification:

Contact rating: 60 Vdc, 100mA

• Normal:

PIN 3 and PIN 4 dry contact output close

- Any alarms happening:
 PIN 3 and PIN 4 dry contact output open
- > Case Grounding:



Panel operation

• A: Display:

It will show the temperature inside the cabinet and system parametric setup.

B: LED indicator:

Power:

- When the system power on and the LED will light in green.
- If any alarm happens, according to flashing times of power led to check the root cause.

Comp.:

- When the compressor is running normally and the LED will light in green.
- ✤ If the system gets into self-test mode and the LED will flash in green.

Fan (In):

When the inner-fan is running normally and the LED will light in green.

Fan (Out):

- When the outer-fan is running normally and the LED will light in green.
- C: Press Buttons:
 - ♦ ↑: UP or increase
 - ✤ ↓: DOWN or decrease
 - SET: Parametric setup
 - ON/OFF ESC: Power on/off or back

2-1-2 Protection

Over current protection:

DC power board: 20A

> Over temperature protection:


DC power board: 95 \pm 4 °C

Under voltage protection:

DC power board: 40 \pm 1.4 VDC

Reverse polarity:

Allow reverse voltage: 42 ~ 58 VDC



Short Ckt:

If compressor UVW short for any both phase the compressor will not operate.


Compressor H/T protection

 $T_{comp}~\geq~105~^{o}C$

Eva L/T protection

 $T_{EVA} < 0 \ ^{\circ}C$

> Power on delay for fans & compressor



3. Environmental Condition

3-1. Operating Temperature

-10 °C ~ +55 °C (14 °F ~ 131 °F)

3-2. Storage Temperature

-40 °C ~ +70 °C (-40 °F ~ 158 °F)

3-3. Operation Humidity

External air loop: 0 ~ 100 % RH Internal air loop: 0 ~ 80 % RH, non-condensing

3-4. Ingress Protection Rating

IP55 (IEC60529) on external side GR487 on external side

4. Reliability Table

Test item	Condition
High temperature	IEC 60068-2-2
Low temperature	IEC 60068-2-1
High temp. / High humidity	IEC 60068-2-3
Temperature cycle	IEC 60068-2-14 test Nb
Vibration	ETSI 300 019-1-4 CLASS 4.1
Ingress protection (external side)	IEC 60529 IP55 / GR487
Salt fog test (external side)	IEC 60068-2-11 severity 4 , 6cycles
Package bump	IEC 60068-2-29

5. Safety Certification

TUV, CE, UL




Part no. :

Delta model no. : HEC0800PB

6. Accessory

Power and Alarm Cable

Pin	Description	Cable wire size
1	DC	14 AWG
2	-48 V	14 AWG
3	N/A	N/A
4	N/A	N/A
5	N/A	N/A




.....

7. Parameters Table

7-1. System Setup

Item	System Parameter	Default	Range
d1.1	System Version	2.5	N/A
d1.2	Alarm Logs	0.0	N/A
d1.3	Inside over-temp. Setup	60 °C	40 °C - 70 °C
d1.4	Auto Self-Test Function	Enable	Enable/Disable
d1.5	Recovery Default	N/A	N/A
d1.6	Photo Coupler Normal Status	Close	Close/Open
d1.7	Password	000	000~999
d1.8	System Re-lock	N/A	N/A
d2.1	Target temperature	30 °C	25 °C - 40 °C



Page 18

7-2. Alarm Logs & Fault Processing

Alarm Indicators

Flash Times (Power Led)	LV1 Alarm	LV2 Alarm	Alarm Code
		Compressor 3-min Protection	
		Compressor Power Protection	
		Low-Temp Startup Protection	
		Eva Temperature Protection	2.1
		Comp-out Temperature Protection	2.2
2	Temperature Abnormal Alarm	PWB Temperature Protection	2.3
		IPM Temperature Protection	2.4
		Amb Temperature Protection	2.5
	Temperature Sensor Fault	Amb Temperature Sensor	3.1
		Eva Temperature Sensor	3.2
2		Cond Temperature Sensor	3.3
3		Comp-Out Temperature Sensor	3.4
		PWB Temperature Sensor	3.5
		IPM Temperature Sensor	3.6
4	Fan Fault	Indoor Fan	4.1
4		Outdoor Fan	4.2
		EEPROM	5.1
5	Controller Fault	Current Sensor	5.2
		DC-Bus Voltage	5.3
	Cooling System Fault	Power Board	6.1
e		Startup Fail	6.2
6		IPM Over Current	6.3
		Compressor Lack Phase	6.4

.....

Part no. : Delta model no. : HEC0800PB


Fault Analysis and Processing

Fault State	Analysis of the Reasons	Solutions
Power on, and the	1.Power failure or no power.	1. Check the power supply and the electric circuit.
cabinet temperature is too high but the air conditioner is not working	2. The target temperature is higher than inside temperature.3. System failure.	2. Re-set the target temperature according to the system requirement.3. Please contact the service department.
	1. The air conditioner capacity is not match the load of the system.	1. Check the heating load of the system.
The air conditioner is running but the cabinet temperature is still high,	2.The ambient temperature is too high.	2.Ensure the air conditioner operates in correct temperature range.
no obvious cooling effect.	3. Low efficiency of the condenser.	3.Clean the condenser.
	4. Other system failure	4. Please contact the service department.
The air conditioner stop operating, and there is no	1. The inside temperature is lower than the target temperature.	1.Re-set the target temperature according to the system requirement.
alarm signal.	2.Other system failure.	2. Please contact the service department.

.....

8. Installation Notice

Check the surrounding obstacles to make sure the product get enough space for air circulate.



At the end of the unit working life, the produce must not be disposed of as urban waste. It must be taken to a special local authority differentiated waste collection center or to a dealer providing this service.

10. Versions

REV.	Description	Owner	Date
00	Issue SPEC	VIC	2015.06.15
01	Modify TUV.CE.UL ICON	REX.LYU	2020.08.13
02	Modify Caution.	REX.LYU	2020.09.15

* \boldsymbol{X} means temporary version